

Assembly, Operating & Maintenance Instructions

JOPLIN, BAEZ SIDE BACK

Remove all items from the carton. Verify all pieces before assembly.





STEP 3.



CARE & MAINTENANCE

GENERAL CARE

To maintain the appearance of non-upholstered parts wipe the surface with a clean cloth dampened with a mild detergent solution.

Do not remove any parts for separate cleaning. Do not saturate the fabric or interior with water or other cleaning liquids.

Do not shampoo clean.

Do not clean with hot water extraction machine. Do not clean with onsite drycleaning machine. Protect from direct sunlight, heat and weather.

UPHOLSTERY CARE

Wipe with a clean cloth dampened with a mild upholstery detergent solution.

A soft bristle brush may be used to remove ingrained soil.

Use only leather care products suitable for top coated leather and strictly in accordance with the manufacturer's instructions

Spot clean as above.

Treat spills and stains as soon as possible. Persistent stains may require treatment by a professional cleaner.

Allow to dry thoroughly before reuse.

Every 6 months, please make sure all bolts, screws and knobs are fully tightened to ensure stability.

If you require assistance with assembly or use, please call Customer Service at 1-866-574-3183.

For full warranty information, please see website www.woodstockmarketing.com.

Woodstock Marketing
PO BOX 5711 Williamsburg.VA.23188
info@woodstockmarketing.com
www.woodstockmarketing.com.

PARTS LIST

KEY	Name	Part	Qty	Spare
(1)	Casters		5	
(2)	Chair base	7	1	
(3)	Gas lift		1	

(4)	Seat/Back Frame		1	
(5)	Arm Spacers	ď	4	
(6)	Armrests		2	
(7)	Armrest screws 5/16"*2-1/4"		4	

PREVENTATIVE MAINTENANCE & WARNING!

- Use this product only for seating one person at a time.
- Do not use this chair as a step stool/ladder.
- Do not sit on any part of the chair except the seat.
- Do not use this chair on uneven floor surfaces.Do not interfere with the operating of the gas lift.
- Do not use chair unless all bolts, screws and knobs are tight. At least every six months check all bolts, screws and knobs to ensure they are tight.
- If any parts are missing, broken, damaged or worn do not use the product until repairs are made using factory authorized parts.
- Dispose of packaging properly.
- · Plastic bag is not a toy.
- Do not use plastic bag as a head covering as it may cause suffocation.
- · Failure to follow these warnings could result in serious injury.